# Keep Your Router From Tipping

***by Bill Hylton***

To eliminate router tipping, try carpet-taping a scrap of the workpiece stock to the baseplate of your router. If you then set the workpiece on a piece of expendable plywood, the block will slide along the plywood and keep the router level. (Also, I've found that the DW621 dust collection works pretty well on this sort of cut.)